




Erpice rotante magnum



CE



Istruzioni per l'uso e manutenzione - Parti di ricambio
Operating and maintenance - Spare parts
Utilisation et entretien - Pièces de rechange
Instrucciones de empleo y mantenimiento - Repuestos
Betriebs- und Wartungsanleitung - Ersatzteile Katalog

breviglieri macchine agricole		CE	
MODELLO	(A)	VERSIONE	(B)
MATRICOLA	(C)	MASSA Kg (D)	ANNO (E)







Fig. 1







Mod.	A	B	C		kW	(HP)	N°			
								525	450	464
	cm	cm	cm					Kg	Kg	Kg
300	120	158	309		74/110	(100/150)	24	1160	1190	1310
350	120	158	362		81/125	(110/170)	28	1260	1320	1460
400	120	158	411		88/147	(120/200)	32	1430	1490	1640

Fig. 2




Fig. 3








Fig. 4

(V.300) 5500185
(V.350) 5500186
(V.400) 5501164













Tav. 5





Tav. 6

























Tav. 14



















Tav. 20




Tav. 21




507080351



6D8868004R




Tav. 22






572080451




6D8868004R




Tav. 23




Tav. 24




5070L0351




6WL269004R




Tav. 25



5070L3751



6WL269004R





BREVIGLIERI Spa

37054 NOGARA (Verona) Italia - Tel. 0442 537411 - Tel. export 0442 537404 - Fax 0442 537444
www.breviglieri.com - E.mail: info@breviglieri.com